

# Medium Conference Room

## Design Guide

DOC-0519-001 REV 1.9 - 08 April 2022

### Room Application

Video Conferencing,  
Teleconferencing

### Included Interfaces

BYOD PC audio and video,  
Bluetooth, VoIP, Analog Phone

### Primary Equipment


- BMA 360
- CP2 48 VT DSP
- BT Expander
- Versa Hub

### Software/Firmware revisions utilized

- CONSOLE® AI Version: 7.5.4.1
- DSP Version: 8.515.0
- BMA 360 Version: 1.0.6.10




### Room Illustrations



### Room Description

A Medium Conference room for groups of 12 or less. This system provides the best audio even in a reverberant space and all of the connectivity needed for BYOD devices from your laptop to your cell phone. Standard Telephony and VoIP complete the systems long list of connectivity options.


Wiring Diagram



**Equipment list:**

Qty	Part Number	Product Name	Description
1	910-3200-008	CONVERGE® Pro 2 48VT	DSP Mixer with 4 Mic/Line AEC Inputs, 8 Mic/Line Outputs, USB Audio, VoIP, Telephone Interface, 2 x 10 Watt Power Amplifier
1	910-3200-209	90W PoE++ power supply kit for BMA	Includes 1 x 90 Watt PoE++ Injector, 2 x 7.6m CAT6 cables
1	910-3200-202	36W PoE+ power supply kit for BMA	Includes 1 x 36 Watt PoE+ Injector, 2 x 7.6m CAT6 cables
1	910-3200-208-I	BMA 360 600mm	BMA with 4 x 15 Watt Power Amplifiers. PoE Injector and CAT6 cables not included.
1	910-3200-302	USB Expander for CONVERGE® Pro 2	Includes 1.8m USB cable
1	910-3200-303	CONVERGE® Blue Tooth Expander	Includes Bluetooth Expander Wall Panel, Trim Plate, Low Voltage 1-Gang Wall Bracket, NFC Button
2	910-151-001-01	Ceiling Speakers	Includes 2 x LS6CT ceiling speakers with 8 ohm and 70V/100V transformer taps and ceiling tile bridges.
1	910-3001-100	COLLABORATE® Versa Hub	Hub that connects USB camera, USB audio, room displays and laptop

**FlowView™ Diagram**



## Included Macros

- Microphone\_Mute : Mutes both room BMA 360 Microphones.
- Microphone\_Unmute : Unmutes both room BMA 360 Microphones.
- Room\_SPKR\_Mute : Mutes all room speaker channels.
- Room\_SPKR\_Unmute : Unmutes all room speaker channels.
- Room\_VOL\_DN : Decreases the room speaker volume by 3 dB per execution.
- Room\_VOL\_UP : Increases the room speaker volume by 3 dB per execution.

\* Macros can be executed via Telnet or serial communications.  
Refer to the Converge Pro 2 Serial Command Reference Manual for details.

## SALES AND INQUIRIES

### Headquarters

Unit 3, 58 Waterway Drive  
Coomera, QLD, 4209, Australia

### Phone

Main: +61 7 5561 7530

### Sales

[sales@avdistributors.com.au](mailto:sales@avdistributors.com.au)

### Tech Support

[support@avdistributors.com.au](mailto:support@avdistributors.com.au)